## **EXO X7 Ranger PLUS**

## Quadcopter

**Dimensions (folded)** 

8 x 4 x 3 in

**Dimensions (unfolded)** 

10 x 10 x 3 in

**Weight With Battery** 

22oz

Max Speed (X Axis)

25MPH +

Max Speed (Ascent)

5 MPH

Max Speed (Descent)

4 MPH

**Maximum Takeoff Height** 

None

**Maximum Wind Resistance** 

Level 5 (19-24 mph)

**Operating Temperatures** 

32 - 100 degree F

Satellite Systems

GPS/GLONASS

**Return to Home** 

Controller, App

**Obstacle Sensors** 

360 horizontal, Downward

**Hovering Accuracy Range** 

<1ft (Optical Flow) <2ft (GPS)

Motor

Brushless

**Speed Levels** 

High, Low

**Downward Spotlight** 

No

## **Range & Battery**

**Max Flight Time** 

25 minute

**Max Transmission Range** 

1/2 mile control, 1500ft live feed

**Max Flight Distance** 

5 miles

**Transmission Latency** 

<500ms

**Transmission Resolution** 

720p

**Battery Type** 

Lithium Ion

**Battery Capacity** 

3400mAh

**Battery Charge** 

Time 3-5h

**Battery Weight** 

170g

Camera

**Max Video Res** 

2K

**Max Photo Res** 

9MP

Sensor

1/3in Sony Sensor

**Stabilization** 

3 Axis Gimbal

**Max Video Bitrate** 

20mbps

**Aperature** 

f/2.8

**FOV** 

80 degree

**Focus Point** 

.5m - Infinity (auto) **ISO Range** 100 - 3200 (auto) HDR No **Night Mode** No Quickshots No **Internal Storage** No **Still Image Size** 7 - 9 Megapixels **Video Resolutions** 2048X1080P (2K, 25FPS) **Photo Format** JPG **Video Format** MP4 **Memory Card Type** 16GB, 32GB (EXFAT) Hyperlapse No Zoom 50X (digital) **General Obstacle Avoidance** None **Smart Features** Follow-Me, Waypoint Fly, Return to Home (x3), 50X Zoom, Find-Drone, Gesture Commands **App Name** Fly Ranger **App Compatibilty** IOS + Android

## **Lost Connection Saftey**

**Low Batery Saftey** 

Yes

Yes

**Gimbal** 

Stabilization

3 Axis Gimbal (tilt, roll, pan)

**Tilt Range** 

-90 degree - 20 degree

Pan Range

+/- 20 degree

**Roll Range** 

+/- 20 degree

**Max Controllable Speed (Tilt)** 

60 degree/s